

Public test session report

Prusa3D Buddy3D
PETG Blue

MaterialID MAT0052



3DPiceland Labs
Generated with 3DPiceland Engineering Platform v60.0.6
WORKFLOW-RELIABILITY - Bug Fixes and Workflow
Reliability
2026-08-25 19:04:35

Traceability boundary: canonical per-module measured dates are shown below. Session identifier, time of day, operator, printer/slicer profile and environmental conditions are Not recorded and are never inferred.

Measurement provenance

Canonical SQLite measured dates use ISO format; missing dates remain Not recorded.

Module	Measured date
Tensile	Not recorded
Impact	Not recorded
Stiffness	Not recorded

Status Complete	Result modules 3/3	Specimen/result records 40	Public details Approved
---------------------------	------------------------------	---	-----------------------------------

Specimen and result quality

Module	Orientation	Average	Std. dev.	CV	Specimens	Confidence	Validation
Tensile	Upright	15,022 MPa	4,872 MPa	0,324%	9	9/10	OK
Tensile	Flat	23,779 MPa	2,431 MPa	0,102%	10	10/10	OK

Module	Orientation	Average	Std. dev.	CV	Specimens	Confidence	Validation
Impact	Upright	92,311 kJ/m ²	16,958 kJ/m ²	0,184%	10	10/10	OK
Impact	Flat	293,182 kJ/m ²	201,622 kJ/m ²	0,688%	10	10/10	OK
Stiffness	Three-point bend	1537,602 MPa	n/a	n/a	1	Complete	OK

Recorded native inputs

Module	Input set	Recorded values
Tensile	Upright force inputs (N)	131, 111, 130, 109, 91, 58, 117, 94, 38,
Tensile	Flat force inputs (N)	153, 155, 165, 149, 157, 177, 145, 119, 156, 170
Impact	Upright needle inputs (%)	4,50, 6,00, 4,00, 5,00, 5,00, 7,00, 6,00, 5,50, 7,00, 5,00
Impact	Flat needle inputs (%)	12,00, 34,00, 8,00, 36,00, 33,00, 8,00, 15,00, 10,50, 9,00, 8,00
Stiffness	Revolutions / degrees	3 / 120

Approved test notes

Method and equipment context

Purpose-built tensile, pendulum impact and three-point bend apparatus are used with the governed Settings Manager constants consumed by ResultsService. Results are comparative and do not claim accredited-laboratory equipment.

[Testing methodology](#) · [Engineering methodology whitepaper](#) · [Download PDF](#)
 reports/test-sessions/MAT0052/